

PROMASEAL/PROMASTOP FIRE COLLAR FIXINGS TECHNICAL NOTE

The purpose of this Technical Note is to clarify the issues with regards to the use of the correct fixings currently available in the market place for fire collars and explain the differences between them.

It is essential that fire collars are only installed with the correct size **ALL STEEL** fixings. In the past alloy based fixings have been tested and have shown that they will not provide the required fire performance.

Currently some fixing products available are marketed as all metal, or zinc alloy. These type of anchors need to be thoroughly checked because some of them have other alloys included in the matrix of the fixing and these can melt at lower temperatures than those found in cellulosic fires, thus rendering them inappropriate for supporting fire resistant devices such as fire collars. Always check!

Some examples of “**all metal, zinc alloy etc**” anchors are:

TABLE 1

Ramset's	Shuredrive	
Macsim's	Macdrive	
Hilti's	HD Metal Drive Anchor	
Power's	Metal Pin Anchor	

THE ABOVE ANCHORS ARE NOT SUITABLE AS FIXINGS FOR PROMAT FIRE COLLARS UNLESS THERE IS TEST EVIDENCE TO SUPPORT THEIR USE.

Some examples of “**all steel**” anchors are:

TABLE 2

Ramset's Dynabolt		Macsim's DBZ Metal Pin Anchor	
Ramset's Trubolt		Macsim's Masonbolt	
Ramset's Redidrive		Power's Sleeve Anchor	
Hilti's DBZ		Power's Powerbolt	
Hilti's HSA Stud Anchor		Power's PBZ Wedge Anchor	

THE ABOVE ANCHORS ARE SUITABLE AS FIXINGS FOR PROMAT FIRE COLLARS IN ACCORDANCE WITH THE TABLES OVERLEAF.

CONCRETE WALLS / FLOORS	PLASTERBOARD WALLS
Fire Collars should be installed on both sides of the wall.	
<p>For PROMASTOP® UniCollar™ installed into concrete walls or floors, steel fixings are supplied within the collar packaging and the collars should be installed with the requisite number of brackets depending upon the pipe size.</p> <p>For PROMASEAL® FC and PROMASEAL® FCS fire collars installed into concrete walls or floors steel fixings must be installed using all the collar fixing points with the following sizes:</p> <ul style="list-style-type: none"> • For collars up to 150mm, 25mm minimum length steel anchors should be used, such as those shown on page 1 Table 2. • For collars from 150mm to 315mm, minimum 38 x 6mm steel expanding anchors must be used, as per Ramset Dynabolt or similar. 	<p>For PROMASTOP® UniCollar™ installed into plasterboard walls, 40mm x No.10 laminating screws are supplied within the collar packaging and should be installed with the requisite number of brackets depending on the pipe size.</p> <p>For PROMASEAL® FC and PROMASEAL® FCS fire collars installed into plasterboard walls, steel fixings must be installed using all the collar fixing points and using the following fixing sizes:</p> <p>For collars up to 150mm, 40 x No.10 laminating screws should be used.</p> <p>For collars above 150mm, framing should be placed within the wall at locations where the following rods pass through. 8mm diameter threaded rod must pass from one side of the wall to the other and washers and nuts should be placed onto the ends of the rods where they pass through the fixing points of the collar.</p>

Plasterboard Ceilings	
PROMASEAL® FC & FCS - up to 160mm	PROMASTOP® UniCollar - up to 110mm
<p>PROMASEAL® FC Retrofit Collars can be installed onto uPVC and HDPE in 60 to 120 minute fire rated ceilings. Use PROMASEAL® AN Acrylic Sealant to seal annular gaps. Provide additional framing to support the collar.</p> <p>Fix the collar through the plasterboard and into the framing above. The gap between the ceiling lining board and the pipe should be no more than 15mm and sealed with PROMASEAL® AN Acrylic Sealant to the full depth of the lining board.</p>	<p>PROMASTOP® UC UniCollar can be installed into fire rated plasterboard ceilings that provide a similar fire rating.</p> <p>For 90 minutes integrity and 60 minutes insulation fit the collar to the ceiling lining with 10g x 40mm coarse thread screws, use 2 brackets for pipes 40mm-69mm and 3 brackets for pipes 70-110mm.</p> <p>For 90 minutes integrity and 90 minutes insulation fix the collar as above but install one layer of PROMATECT® L500 board locally above the collar friction fitted between the joists.</p>

AUSTRALIA

Promat Australia Pty. Ltd.
 1 Scotland Road
 Mile End South, SA 5031
 Tel: 1800 PROMAT (776 628)
 Fax: +61 (8) 8352 1014
 Email: mail@promat.com.au

New South Wales Office

Promat Australia Pty. Ltd.
 Unit 1, 175 Briens Road
 Northmead, NSW 2152
 Tel: 1800 PROMAT (776 628)
 Fax: +61 (2) 9630 0258
 Email: mail@promat.com.au

Victoria Office

Promat Australia Pty. Ltd.
 Suite 205, 198 Harbour Esplanade
 Docklands, VIC 3008
 Tel: 1800 PROMAT (776 628)
 Fax: 1800 334 598
 Email: mail@promat.com.au

Queensland Office

Promat Australia Pty. Ltd.
 1/68 Lisgar Street
 Virginia, QLD 4014
 Tel: 1800 011 376
 Fax: 1800 334 598
 Email: mail@promat.com.au